

# ISOKERIN®

## Fireplaces & Chimneys

### BOTTOM MOUNT DAMPER INSTALLATION INSTRUCTIONS

The MMR is a gravity damper for See-Through fireplaces where a conventional or top mount damper is not an option.

Mounts to the bottom side of the top plate inside the smoke dome.

For ease of installation install on the smoke dome before installation on the smoke chamber.

Place the damper against the bottom of the top plate with the flange and wire loop in a position where the damper door will fall open when the dome top is placed on the smoke dome.

Make and drill pilot holes for the eight (8) anchor screws (3/16" x 1 3/4").

Use a drill bit 1/8" or smaller.

Do not over tighten.

Drill pilot holes at a slight angle away from the dome opening.

Measure the cable and chain and attach as illustrated making no final cuts or crimps until proper action is accomplished by positioning the guide/lock bracket where the damper door can be easily opened or locked closed. If properly installed, upon releasing the chain the damper door will fall open.

If the damper is being installed in a completed fire-box be sure to clean any excess mortar from the around the opening so the damper will fit flat against the bottom of the smoke dome.

